
TROOPER INSTRUCTION MANUAL Art. No.: 24065



Attention:

Please pay attention that the setting time for the date is restricted and shall not be executed between 4 o'clock p.m. and 4 o'clock a.m. This is due to construction limitations and in case of infringement parts of the mechanism could be damaged.

Setting the date:

- 1. Pull out crown to position 1 and rotate crown to set date.
- 2. Push back crown to original position to start time when date is set.

Setting the time:

- 1. Pull down the crown out into position 2.
- 2. You can now adjust the time by means of turning the crown.
- 3. Push the crown back into its initial position.
- 4. Now wind the crown carefully clockwise approximately 20 times. When the watch is normally worn on the wrist the winding will be done automatically through the motion of your arm.

Please note that, when you haven't worn the watch for many hours, you might have to wind it up manually first. When fully winded up the watch's power reserve can last up to 36 hours.

DISPOSAL:

The packaging material is reusable. Dispose of the packaging in an environmentally friendly way by putting it in the appropriate recyclable waste collection containers.



Dispose of the product and the batteries in view of the environment if you want to

separate. The device and the batteries must not be thrown in with domestic waste.

Take them to a recycling center for used electrical and electronic devices.

For more information you can consult your local government. Remove batteries first.

Eurotops Versand GmbH Elisabeth-Selbert-Straße 3 40764 Langenfeld, Germany



If technical support is needed, please call ...

0180 . 530 63 63* or info@eurotops.de in Germany 01 . 230 60 43 12 or info@eurotops.at in Austria 044 . 28 36 125 or info@eurotops.ch in Switzerland in the Netherlands 026 . 37 36 333 or info@eurotops.nl in France 0892 . 700 470** or info@eurotops.fr

A possible return of products should be addressed to the return address stated on your invoice.

The manual only reflects the technical conditions available under printing. Any changes in technology and equipment are reserved.

© 17.10, 2013

^{* 14} Cents/minute via German landline, max. 42 cents/minute via mobile phone network **34 Cents/minute via French landline