

    
**BRAUN**<sup>®</sup>

## BIKE CAM

CAM + LIGHT + POWER BANK



USER'S MANUAL  
ENGLISH

Thank you for choosing a BRAUN<sup>®</sup> product.

Enjoy your ride with the new **BIKE CAM!**




## SAFETY WARNING

- Read the safety instructions carefully and keep them for future use.
- Pay attention to all warnings and warning signs on the product.
- Do not look directly or illuminate others' eyes.
- Place this product out of the reach of children.
- Product needs to be isolated to humidity.
- Keep away from heat sources and fire.
- Do not pour liquid or insert other objects into the product.
- Do not open the product and try to maintain it by yourself.
- Please contact the nearest dealers to obtain after-sales service.


Artikel-Nr. / Item no. 57670

## PRODUCT LIST

1) Action Camera





2) Bracket



## MOUNTING METHOD

Handlebar of bicycle or motorcycle mounting





    
**BRAUN**<sup>®</sup>

BRAUN Photo Technik GmbH  
Merkurstrasse 8  
72184 Eutingen/Germany



[www.braun-phototechnik.de](http://www.braun-phototechnik.de)

## INTERFACE EXPLANATION



## PRODUCT SPECIFICATIONS

- Light Source: CREE WHITE LED 5W
- Luminous Flux: > 600 LM
- Battery capacity: 6600 mAH
- Lighting Mode: dim light, bright light, SOS
- Battery last approx. 6–10 hours in only light mode
- Battery last approx. 14 hours in only video mode
- Charging time approx. 7 hours
- Input 5V 1A
- Output 5V 1A Power bank function
- Working temperature range -20 – 70°C
- 1080p HD video with audio
- 5.0 MP HD camera
- Supports up to 32 GB memory card (microSD)
- Product weight: 315 g
- Product size: 114 x 69 x 34.5 mm

## FUNCTION INSTRUCTION

### 1) Function operation and instruction

- POWER:** Long press for ON/OFF, short press for camera mode, video mode, driving mode or playback mode. Short press in playback mode and setting mode to exit.
- Move the cursor up and down:** Press **RIGHT** to shift to setting mode when camera mode is activated.
- OK:** Take pictures or confirm.
- Light:** Shift of light mode, low light/bright light/SOS/flash/OFF.

### 2) Micro USB Mode

Plug in cable to connect computer and to read the data from microSD card. If there is no microSD card available, then PC CAM mode will be ready.

### 3) Auto Shutdown

- Auto shutdown when memory card is full.
- Auto shutdown when USB cable pulls out in USB storage mode.
- Auto shutdown when battery level is less than 3.5 V.

### 4) Memory card format function

Press „RESET“ to shut down and then boot when it is in abnormal crash state.

### 5) Battery charging

Micro USB is the charging port. Please use the included charger.

### 6) Mobile power function

USB / 5V1A is the port used to charge the external device.

