

Instructions for use 2426943

Spark Lighter

Instruction

1. Cozy Arc is a safety device in drawer type with switch.
2. When using the electric arc cigarette lighter, press and hold the switch button, then **to push.**After arc device pop out of the body, delay 2 seconds to get arc.

Press and Pull the switch button back, the arc device is switched off.

3. Cozy Arc can be connected to all the devices which have output voltage DCV5 and out put current 1.0A to charge by USB including computers and phones. When charging, the pilot lamp at the bottom of the lighter will be shining. For your safety, the inside circuit is automatic disconnected and the lighter can't be used during charging process.
4. Cozy Arc electric arc lighter is equipped with protection against over-charging and over-discharge. The ignition time limit to 6-7 seconds, it's normal if it extinguishes after 7 seconds.

Attention

1. After charge, pls disconnect the electricity in time, since long-term charging affect the life time of battery.
2. Please do not put the lighter into fire, water or other liquid.
3. Please charge in time. When power run out, arc will be thin and pilot lamp will flash

Maintainance

1. Use a soft cotton cloth to cleanse the surface.
2. The metallic surface glossing will be declined after being used a period of time
3. It is recommende to charge the lighter once every six months if not be used for a long time, this will protect the battery life from the **damage of the excessive discharge.**

Technical data

Never charge the battery for more than 2 hours.

Rechargeable battery 1xbiult-in Li-on,

180 mAh Rechargeable battery charge time approx. 2 hour