




T1/T2/T3/T4/T5/T6		C1	C2
6PCS		2PCS	2PCS
E1		E2	
2PCS		2PCS	
E3		E4	
1PC		2PCS	
E5	A1	A2	A3
4PCS	16PCS	6PCS	6PCS
B1			
	Allen key		
16PCS	1PC	2PCS	




With the aid of an Allen key, use four socket screws(B1) to attach the two smaller end panels (E1) to the long side panel(E2).




Slide the play area(E3) into the assembled construction as shown in illustration 2.




Slide the rings(A1) onto the metal bars(T1, T2, T3, T4, T5, and T6).




Insert the metal bars(T1, T2, T3, T4, T5 and T6) into the designated holes in the long panel.




Attach the second side panel as described in illustration 1.



Slide the six handle bars(A2), and pin the six stoppers(A3) tightly onto the metal bars as shown in illustration 6.



Turn the handle bars (A2) all the way to the stop. Use screws(B1) to attach legs(C1, C2) to side panels.



Attach the two score scales(E4) to the designated holes with the aid of the fixation parts(E5), E4&E5 to the panels(E1).